



national

Installation Instructions

1. Where the wall was primed, sand it with a sanding pole and 80 grit sandpaper to knock the shine off the primed wall; this will allow the adhesive to penetrate.
2. Wipe the walls with a rag to remove the dust.
3. Purchase and use Roman's 111 adhesive only. Please note: If any other adhesive is used, the material will not be warranted.
4. Use a ½" roller to apply a **light coat** of adhesive to the wall.
5. Allow the adhesive to become tacky, begin with 3-4 sheets at a time of the Real Wood Veneer and place it face down.
6. Use a cellulose damp sponge and wet the back of the sheets of veneer. The backing should be wet to the touch, but not dripping with water.
7. Once the wall is tacky, take the damp sheets directly to the wall and install.
8. Smooth the material down with a plastic smoother, ensuring you overlap and double the material with a new razor at each cut.
9. Using a damp sponge, remove adhesive from the surface. If the adhesive is not dry, do not scrub on the surface of the wood; let it dry for 24 hours and come back and surface clean with a damp sponge.

Caution: If you get the surface of the wood super soaked and you have wet adhesive on the back of the goods, it can make your seams pop! **DO NOT PANIC**.... let the adhesive dry on the surface. This will ensure that the wood is adhered to the wall soundly. You can surface clean in 24 hours with a DAMP sponge.